

Sperm preparation

Density gradient centrifugation method

Day -1

The day before oocyte pick-up



Pre-equilibrate Gx - IVF at

**37°C 6 % CO₂
overnight**



Pre-rinse all utensils, including tubes and dishes, with G-RINSE.


Day 0

1. Assess the semen sample

2. Prepare gradient solutions



or



If you use SpermGrad RTU go to paragraph 3.

Dilution of SpermGrad

Mix SpermGrad with Gx-IVF in separate rinsed tubes to obtain 90 % and 45 % stock solutions. For 90 % stock solution, mix 9.0 mL SpermGrad with 1.0 mL Gx-IVF and for 45 % stock solution, mix 4.5 mL SpermGrad with 5.5 mL Gx-IVF.

3. Prepare gradients

Pipette 1.5 mL of the 90 % solution into the rinsed tube first and then slowly pipette 1.5 mL of the 45 % solution on top of it. Finally, 1.0 mL of the semen is layered on the top.



Make up 2-4 gradient tubes. Before use, allow the stock solutions to warm to ambient temperature.

4. Centrifuge the gradients at

300-600g 10-20 min

5. Wash I

Remove the two top layers. Transfer the pellets to new rinsed tubes and re-suspend with 5 mL equilibrated Gx-IVF and centrifuge again at



300-600g 10 min

6. Wash II

Aspirate and discard the supernatant. Transfer the pellets to new rinsed tubes and re-suspend with 5 mL equilibrated Gx-IVF and centrifuge again at



300-600g 10 min

7. Assess sperm preparation

Aspirate and discard the supernatants. Combine all pellets in a new rinsed tube and re-suspend in 0.5-1.0 mL of equilibrated Gx-IVF depending on sample quality.



Determine motility and concentration of spermatozoa in the washed sample.

8. Dilution

Dilute with equilibrated Gx-IVF to a final concentration of 75,000-200,000 motile sperms/mL.

9. Preparation of insemination dishes

Prepare rinsed insemination centre well dishes with 0.5-1.0 mL of sperm solution and pre-equilibrate.



If oil overlay is used, droplets of at least 100 µL volume are recommended. Equilibrate the dishes at

37°C 6 % CO₂ >2 h

10. Insemination

Transfer the oocytes to the insemination centre well dishes and leave at

**37°C 6 % CO₂
overnight**

Alternatively: Add equilibrated sperm suspension to equilibrated centre well dishes with the oocytes already present.